



**MANUAL DE INSTRUCCIONES  
MINI-PARLANTE C/BLUETOOTH  
MS-5193SDBT**



***ESTIMADO CLIENTE***



Con el fin de que obtenga el mayor desempeño de su producto, por favor lea este manual de instrucciones cuidadosamente antes de comenzar a utilizarlo, y guárdelo para su futura referencia.

Si necesita soporte adicional, no dude en escribir a: [info@premiermundo.com](mailto:info@premiermundo.com)



## ÍNDICE

CONTENIDO .....	2
DESCRIPCIÓN .....	2
FUNCIONES DEL PARLANTE .....	2
LUZ INDICADORA .....	3
BATERÍA .....	3
BLUETOOTH .....	3
MODO DE TARJETA.....	4
TRANSMISIÓN DE DATOS.....	4
INSTRUCCIONES DE SEGURIDAD .....	5
ESPECIFICACIONES .....	5

	<b>PRECAUCIÓN</b> <b>RIESGO DE CHOQUE ELÉCTRICO , NO ABRA</b>	
<p>Precaución: Para reducir el riesgo de choque eléctrico, no retire la cubierta, no hay partes manipulables por el usuario al interior de la unidad. Refiera todo mantenimiento o intervención técnica a personal técnico calificado.</p>		
	<p>Este símbolo indica la existencia de voltaje peligroso al interior de esta unidad, que constituye un riesgo de choque eléctrico.</p>	
	<p>Este símbolo indica que hay importantes instrucciones de operación y mantenimiento en la literatura que acompaña a esta unidad.</p>	

## LÍNEAS DE SERVICIO AL CLIENTE PREMIER

<b>Venezuela:</b>	0800 – ELECTRIC (353-2874)
<b>Panamá:</b>	300-5185
<b>Sitio Web:</b>	<a href="http://www.premiermundo.com">www.premiermundo.com</a>
<b>E-mail:</b>	<a href="mailto:servicioalcliente@premiermundo.com">servicioalcliente@premiermundo.com</a>


### NOTA

Nos reservamos el derecho de modificar las especificaciones, características y/u operación de este producto sin previo aviso, con el fin de continuar las mejoras y desarrollo del mismo.

## CONTENIDO

- 1 parlante Bluetooth
- 1 cable de datos USB
- 1 adaptador AC
- 1 manual del usuario

## DESCRIPCIÓN



1. Luz indicadora
2. Encender/Apagar
3. Play/Pausa
4. Ranura micro USB
5. Conector de audio 3.5 mm
6. Ranura de micro tarjeta SD

**Botón +:** Siguiente Pista (presione de manera corta) / Aumentar Volumen (presione de manera larga)


**Botón -:** Pista Anterior (presione de manera corta) / Disminuir Volumen (presione de manera larga)

**Play/Pause:** En el modo de Bluetooth, si no hay llamadas entrantes, presione este botón para pausar la música, y una vez para reanudarla. Si hay una llamada entrante presiónelo para contestar y para colgar.

**Botón de Modo:** Presione de manera corta para cambiar de modo: MP3, Bluetooth, Aux In. Presione de manera larga para encender y apagar la unidad.

## FUNCIONES DEL PARLANTE

- Conexión Bluetooth 2.0 para todos los dispositivos con esta función.
- Micrófono incorporado para que utilice el dispositivo como manos libres.
- Reproducción de micro tarjeta SD.
- Batería recargable de larga duración. Hasta 3.5 horas de operación.
- Cable USB con doble funcionalidad: para cargar el parlante y para transmitir datos.
- Soporte de entrada de audio con conector 3.5mm.



## LUZ INDICADORA

Azul: parlante encendido.

Rojo: modo MP3. Parpadea de manera lenta cuando está leyendo la tarjeta de memoria.

Azul parpadeante: modo Bluetooth. Luego parpadea de manera corta cuando se ha enlazado con dispositivo, y se mantiene encendida cuando tiene una llamada.

Rojo brillante: modo Auxiliar.

## BATERÍA

Usted puede disfrutar de hasta 3.5 horas con la batería recargable incorporada.

Antes de usar la batería por vez primera cárguela por 10 horas para obtener el mejor desempeño. Luego sólo será necesario cargarla por 2 horas. Si no la va a utilizar por un período prolongado se recomienda cargarla al menos una vez al mes.

## AHORRO AUTOMÁTICO DE ENERGÍA

Si la operación se pone en modo de pausa por más de 2 minutos, el parlante se apagará automáticamente.

## BLUETOOTH

Verifique que el dispositivo que quiere conectar cuente con la función Bluetooth.


Encienda el parlante manteniendo presionado el botón de encendido hasta que escuche un sonido “ding dong”. El parlante comenzará en la primera función por defecto que es Bluetooth y la luz indicadora se encenderá de color azul y parpadeará rápidamente para buscar su dispositivo.



Cuando el parlante y el otro dispositivo Bluetooth se enlacen, el dispositivo Bluetooth recibirá una señal mostrando el modelo del parlante MS-5193SDBT. Introduzca la contraseña por defecto 0000 para completar el enlace.


## CONTESTAR UNA LLAMADA ENTRANTE

Si está reproduciendo música en el parlante y se recibe una llamada telefónica, la música se pausará automáticamente y entrará al modo de llamada. Presione el botón Play/Pausa en el parlante para contestar. Con el micrófono incorporado en el parlante usted será escuchado perfectamente.



## ***MODO DE TARJETA***

Inserte una tarjeta SD en la ranura y seleccione el modo de tarjeta SD del parlante. Utilice los botones normalmente para reproducir la información de la tarjeta.



Ranura de Tarjeta SD

## ***TRANSMISIÓN DE DATOS***

Al conectar el parlante al computador por medio del cable USB usted puede transmitir información del computador al parlante. Utilice el parlante como una memoria USB tradicional en la cual puede añadir o eliminar datos.

Recuerde no desconectar el cable USB cuando se está haciendo una transferencia de datos.



## INSTRUCCIONES DE SEGURIDAD

- Mantenga la unidad fuera del alcance de los niños.
- Evite que la unidad se caiga y se golpee.
- Mantenga la unidad lejos del agua y no la coloque en lugares con temperaturas muy altas son muy bajas.
- No intente reparar la unidad usted mismo. Remita toda revisión, mantenimiento y reparación a personal de servicio técnico calificado.

## ESPECIFICACIONES

Categoría	Elemento	Especificación
<b>Bluetooth</b>	Versión	Bluetooth 2.0
	Frecuencia	2.4 – 2.48GHz
	Rango de operación	10 metros
	Protocolo de comunicación	HS/HF, A2DP, AVRCP
<b>Audio</b>	Unidad de controlador	50.8mm
	RMS	3 watts
	Frecuencia	100Hz – 18KHz
	Relación señal a ruido	≥50dB
	Impedancia	2.6 ohm
	Distorsión	≤20%
<b>Soporte de archivos</b>	Formatos de música	MP3
<b>Tarjeta de memoria</b>	Soporte	Micro Tarjeta SD
	Lectura de tarjeta	Función activa
<b>Energía</b>	Batería	Li-on recargable
	Voltaje	DC 3.7V
<b>Puertos</b>	Puerto de carga y de datos	Puerto Micro-USB

- 
- Las personas y/o Marcas registradas en este manual de instrucciones no están afiliadas a Premier Electric Japan Corp. y aparecen en este Manual con propósitos ilustrativos únicamente.



**MANUAL DE INSTRUCCIONES**  
***Bluetooth Speaker***  
**MS-5193SDBT**







***DEAR CUSTOMER***

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.

If you need extra support, please write to [info@premiermundo.com](mailto:info@premiermundo.com)



	<b>CAUTION</b> <b>RISK OF ELECTRIC SHOCK, DO NOT OPEN</b>	
<p>Caution: To reduce the risk of electric shock do not open this device, there are not serviceable parts for customers. Please refer any maintenance or repair to qualified personnel.</p>		
	<p>This sign means the existence of dangerous voltage at the inside of the unit, which states a risk of electric shock.</p>	
	<p>This sign means that there are important instructions of operation and handling in the manual that comes with this device.</p>	

### ***PREMIER CUSTOMER SERVICE***

<b>Venezuela:</b>	0800 – ELECTRIC (353-2874)
<b>Panama:</b>	300-5185
<b>Website</b>	<a href="http://www.premiermundo.com">www.premiermundo.com</a>
<b>E-mail:</b>	<a href="mailto:servicioalcliente@premiermundo.com">servicioalcliente@premiermundo.com</a>

### **NOTE**


This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

## Chapter 1: Simple Instructions


### 1.1 Accessories

- Bluetooth speaker×1
- USB Power/data cable×1
- AC Adapter×1
- User guide×1

### 1.2 Outer Constructions



1 2 3



4 5 6



+NEXT/VOL+

Short press: play next song

Long press: increase volume



-PREV./Vol-

Short press: play songs before

Long press: reduce volume



Play/Pause

In Bluetooth mode, if no calls coming, click the bottom to stop

music, click again to play again; if has call coming, click to answer

the phone, the click again to hang up



Switch mode

Short press: switch mode(MP3□Bluetooth□AUX)

Long press: Power ON/OFF



System sight



Power ON/OFF



Play/Pause

**4** Micro USB slot

**5** 3.5mm audio interface

**6** TF card slot

## Chapter 2: Speaker Functions

### Bluetooth, Wireless

Bluetooth 2.0 for all of your devices with builtin Bluetooth function.

### Built-in Mic, Answer the phone

Built-in Microphone gives you a hands-free call, press the phone button answer the phone under Bluetooth mode.

TF card play

### Support TF card

Built-in li-on, strong battery life


Rechargeable LI-ON battery with a long working time up to 3.5 hours.

### One cable, two function

The USB cable with it can use to charge your speaker and also can transmit data .

### Support audio input

3.5mm audio interface fit any music device, let you enjoy music with out any obstacle.



## Chapter 3: system light explain


Power on state: default light is blue after starting.

MP3 mode: red light bright when entering the MP3 mode, flashing slowly when reading memory card

Bluetooth mode: Blue light flash quickly, it will flash slowly after paired with your device and it's always on when calling.


Charge mode: red light is always on and Blue light flash quickly when charging, both light flash alternately when the battery is full.

AUX mode: red light bright.



#### Chapter 4: Li-on battery Notice

You will enjoy music up to 3.5 hours, as there is 1 built-in high capacity rechargeable li-on battery,



##### 4.1 Precautions

To activate its best performance of the battery, please charge the speaker up to 10 hours before you first use it.

You should charge it for 2 hours normally.

Every month you need to recharge it one time at least if you don't use it for a long time.


##### 4.2 Automatic power saving

The Speaker pause playback in 2 minutes without any operating will automatically be turned off.

#### Chapter 5: Bluetooth wireless connection

5.1 Check if your device has bluetooth functions, if yes, turn it on.


5.2 Turn on your speaker by press/hold the power on/off button until you hear a sound of "dingdong". Then it will go into the 1st default mode "bluetooth" and the blue indicator light will flash quickly to search your bluetooth device.




5.3 When your speaker and other bluetooth device find them each other. Your bluetooth device will receive a signal saying "MS-5193SDBT". Please enter the default password "0000" and then they will be paired successfully. If you are fail to pair them, pls try it again as per these steps above.

#### 5.4 Answer Incoming Phone

When the music player,Bluetooth connectivity,if the speaker phone calls detected, the music will automatically pause the playback,into the state of incoming calls,Auto-reply incoming calls,after conclusion of the current current operating mode.

There is an incoming call, a short click  to answer the call. Speaker Built-in microphone,will bring you a clear voice experience.



#### Chapter 6: TF Card Mode

Turn on the speaker into card reader mode(TF Card) by default,you



+NEXT/VOL+

Short press: play next song


Long press: increase volume



- PREV./Vol-

Short press: play songs before

Long press: reduce volume



play immediately after TF card insert

immediately after TF card insert

## Chapter 7:Data transmission

### 7.1 Setup mode basic operation

-Speakers turned normal boot into the USB card reader connected to the computer at the same time.The computer prompts found removeable storage devices.Supports both USB audio modes:normal boot to connect the computer into the USB audio can control music player.


-PC(My computer) can use removable storage of devices directly to the speakers increased file or delete operation.

### 7.2 Frequently Asked Questions

-The speaker data transmission function can only be enabled in the boot state.Data transfer function(also known as the card reader function),must be the speakers is switched on,and then run with computer interconnection,when the speaker shut down, it is invalid.

-If it is connected to the computer failed to show found removable storage devices,check if the speaker is turned on,then check USB data cable is plugged in both ends,at last check the computer USB port.Avoid the computer USB port poor contact data transmission unsuccessful.

-if all USB port does not respond, you will need to reinstall the drives---USB Composite Devece & USB Mass Storage Device. First uninstall those drives, then use USB digital cable to connect with your computer, it will automatically reinstall these two drivers.



## chapter8:Specifications

Category	Item	Specifications
<b>Bluetooth</b>	Version	Bluetooth 2.0
	Frequency	2.4~2.48GHZ
	Working Distance	10m
	communication protocol	HS/HF,A2DP,AVRCP
<b>Auduo</b>	Driver unit	50.8MM
	RMS	3W
	Frequency	100HZ~18KHZ
	SNR	S/N≥50DB
	Impedence	2.6Ω
	Distortion	THD≤20%
<b>Supported files</b>	Music format	Mp3
<b>Memory Card</b>	Support	TF Card
	Card Reader	Card Reader function
<b>Power</b>	Battery	Built-in rechargeable Li-on battery
	Volt	DC 3.7V
<b>Ports</b>	Charge/Data port	Micro USB Port

Warnings:

1. Not toys for Children
2. To avoid/minimize artificial damage, Please do not beat it crazily or drop it onto the solid floor.
3. Free your speaker from water, high Temperature, and too cold conditions.
4. For any function problems, please send them back to the service center, Pls do not open it privately, if you are not an electronic engineer.
5. After a long time using, maybe there will be some natural oxidized issues (like rusts, painting-droop off). Such issues are not in our guarantee service.